# BEAM

QUICKSTART GUIDE

BEAM KEYBOARD

Controlling your BEAM is easy using the keyboard.

Please make sure that:

1

Batteries are equipped and that the **yellow saftey ribbon** is pulled out.

2

The **toggle** on the side of the keyboard is on and its green background is visible.

3

Navigate and control your obie using the **keyboard's trackpad**.

CONTROL AREA

You can always access the control area on your device by pressing **CTRL+Q**.

CONTROL AREA

The control area is divided to 4 sections:

GAMES
Control your games and playlist.

SETTINGS
View and control your BEAM's settings.

PROJECTOR
Turn the projection off, manage device schedules and the adjust the projection.

INFO
View the device, components and software information relevant when contacting support.

Navigate between the sections through the top menu bar

GAMES

Control your games and playlist.

1 **INSTALLED GAMES**
A list of all the games installed on your BEAM.

2 **GAME ROW**
Click on a game row to select that game. You can select multiple games.

GAMES

Control your games and playlist.

(1) ADD SELECTED GAMES

Once you've selected several games from the Installed Games list, click on the **ADD >> button** to add them to the Playlist. Click on the **ADD ALL >> button** to add all the installed games at once.

(2) PLAYLIST

This list contains all the games set to be played.

(3) DELETE PLAYLIST

Clear all the games in the playlist - you can always add them again from the Installed Games list.

Note

You can also click the **ADD ALL >> button** to select and add all the installed games to the Playlist.

GAMES

Control your games and playlist.

1 **SET PLAYLIST GAMES' DURATION**
Edit the seconds field and click the **SET button** to change the duration for all the games currently in the Playlist.

2 **SET A GAME'S DURATION**
Edit the seconds field to change the duration of a specific game in the Playlist.

3 **ORDER ARROWS**
Click the **arrow buttons** to change the game order in the Playlist.

4 **REMOVE GAME**
Click the **remove button** to remove a specific game from the Playlist.

GAMES

Control your games and playlist.

1 **LAUNCH PLAYLIST FROM A SPECIFIC GAME**
Click the **play icon** to start the Playlist from a specific game.

2 **LAUNCH PLAYLIST**
Start playing the games in the playlist.

GAMES

You can also play a single game without creating a Playlist:

(1) SELECT A SINGLE GAME
By clicking the specific game row in the Installed Games list.

(2) SET GAME
Click on the **SET >> button** to set the selected game. This will remove all the games in the existing playlist.

(2) LAUNCH PLAYLIST
Start playing the set game. As it has no set duration, it will continue playing indefinitly until you decide to stop it.

PROJECTOR

Turn the projection off, manage device schedules and the adjust the projection.

①
ADD SCHEDULE
Create a new operating schedule

②
EDIT SCHEDULE
Change the times and days of a schedule

③
DISABLE/ENABLE A SCHEDULE
Disable/enable a schedule

Games Projector Settings Info

Device Schedule   ADD SCHEDULE ①

09:00 – 18:00 ②   ③   **Projector**
Sun   TURN ON

10:00 – 19:00   TURN OFF
Sun, Mon, Tue
                                                        PROJECTION

11:00 – 20:00   **Night saving**
Sun, Mon, Tue, Wed, Thu   OFF

                                                    Schedule
                                                    Active

PROJECTOR

Turn the projection off, manage device schedules and the adjust the projection.

1 TURN PROJECTOR OFF
And enter the device to Sleep Mode.

2 PROJECTION
Rotate or flip the projection

3 DISABLE/ENABLE NIGHT SAVING
When Night Saving is enabled, your device will shut down every night between 1 to 7 AM. Night Saving supersede all schedules.

4 DISABLE/ENABLE ALL SCHEDULES
This setting controls all schedules. If disabled, no schedule will operate, even if it's status is enabled.

SCHEDULE

Edit a schedule by clicking on its row in the Projector screen. Change the times and days of a schedule by selecting to edit them.

1 **START/END TIMES**
Select a time to change it

2 **ACTIVE WEEK DAYS**
Select the days for this schedule

3 **SAVE**
Save your changes

3 **DELETE**
Delete this schedule

Games Projector Settings Info

Edit schedule

1

Start time End time

09:00 18:00

SAVE **3**

DELETE **4**

2 Sun Mon Tue Wed Thu Fri Sat

SETTINGS

View and control your BEAM's settings.

1 ## CONNECT TO WIFI

View all available WIFI netwroks and select one to connect to.

Note

An Ethernet cable connection is recommended for internet access. No configuration is required - just plug it into the network port on Beam.

Network port

Games   Projector   **Settings**   Info

Internet

IP: 192.168.0.56

Internet connected

Connected To: Ethernet

CONNECT TO WIFI   **1**

Change Time Zone

SET   Israel Daylight Time +0300

Daily Reboot

SET   Every day at: 02:00

Calibration   Floor Mode

CALIBRATE

SETTINGS

View and control your BEAM's settings.

1 **CHANGE TIME ZONE**
Select your device's time zone.

1 **DAILY REBOOT**
Set when your device will reboot each day. This will not be affected by any enabled schedules or Night Savings.

3 **CALIBRATION**
Calibrate the motion tracking to the projection.

Note

Calibration is required after **flipping** or **rotating** the projection (through the projection button in the Projector section), or if your BEAM doesn't respond to your movements correctly.

Games   Projector   **Settings**   Info

Internet

IP: 192.168.0.56

Internet connected

Connected To: Ethernet

CONNECT TO WIFI

Change Time Zone

1 SET   Israel Daylight Time +0300

Daily Reboot

2 SET   Every day at: 02:00

Calibration Floor Mode

3 CALIBRATE

INFO

View the device, components and software information relevant when contacting support.

General

Unit S/N: QA5

Tinker S/N: 190550372201072

TV ID: 1576783101

License type: Unlimited

Expiration date: 2999-12-31

Maintenance expiration date: 2016-12-02

Maintenance program: None

Current Date: Mon Jun 15 2020 11:50:39 Israel Daylight Time +0300

SW components

Admin version: 3.1.6.28

Engine version: none

Content

Bundle: Android Beam Floor

Type: Floor

Branding: Beam 1.0.0

HW components

Camera model: Primesense

Screen: 1280x800: 160

Camera S/N: QA-5

PC model: Dell Optiplex 3020M

PC service tag: QA-5

Projector model: BenQ MX620ST

Projector S/N: QA-5

Lamp Usage: none

Lamp daily average usage: none

Last SF sync: 2020-06-15 08:48:51

ENJOY YOUR BEAM!

For any issues or questions, please contact us

Email: **support.team@eyeclick.com**

Website: **https://support.joinbeam.com/open-support-ticket/**